


LifeFitness

LIFE CYCLE LC9500HR

END OF LIFE



Customer Support Services **PARTS MANUAL**


Manual	Part Number
Service Manual	M051-00K46-B004
Operator Manual	M051-00K20-B125
Installation Instructions	M051-00K20-A287
Hardware Kit	AK46-00065-0000

	Page
Frame Components	4
Side Shrouds, Handlebar Shrouds and Cap.....	5
Alternator, Wheels, and Stabilizer Bar	6
Console Assembly	7
Accessory Tray	8
Handlebar Assembly.....	9
Crankarm Assembly	10
Freewheel Pulley/Clutch Assembly.....	11
Idler Arm Assembly.....	12
Seat w/Seat Post Assembly.....	13
Seat Plunger Assembly	14
Alternator Control Assembly	15



Life Cycle LC9500HR

Frame Components



LC95-0XXX-10



Side Shrouds, Handlebar Shrouds and Cap




Alternator, Wheels, and Stabilizer Bar




Console Assembly
 AK46-00064-0001 Eng/Met
 AK46-00064-0003 Ger/Eur
 AK46-00064-0004 Spn/Eur
 AK46-00064-0005 Spn
 AK46-00064-0006 Eng
 AK46-00064-0007 Frn/Eur
 AK46-00064-0008 Itl/Eur
 AK46-00064-0009 Dut/Eur
 AK46-00064-0010 Frn
 AK46-00064-0011 Por


Overlay Bezel Assembly
 AK46-00047-0001 Eng/Met
 AK46-00047-0003 Ger/Eur
 AK46-00047-0004 Spn/Eur
 AK46-00047-0005 Spn
 AK46-00047-0006 Eng
 AK46-00047-0007 Frn/Eur
 AK46-00047-0008 Itl/Eur
 AK46-00047-0009 Dut/Eur
 AK46-00047-0010 Frn
 AK46-00047-0011 Por



Console Case (Grey)
0K36-01187-0007



Battery Cover
0K36-01035-0005






Life Cycle LC9500HR
Handlebar Assembly

LC95-0XXX-10
SK46-00013-0001





NOTE: Bearing Kit Number GK18-00004-0023

